

ALLEN & HEATH



GLD Digital Audio Mixing System

User Guide

Publication AP8561

— *Provisional Release B* —

Limited One Year Manufacturer's Warranty

This product is warranted to be free from defects in materials or workmanship for period of one year from the date of purchase by the original owner.

To ensure a high level of performance and reliability for which this equipment has been designed and manufactured, read this User Guide before operating.

In the event of a failure, notify and return the defective unit to the place of purchase. If this is not possible then please contact the authorised ALLEN & HEATH distributor or agent in your country as soon as possible for repair under warranty subject to the following conditions:

Conditions Of Warranty

The equipment has been installed and operated in accordance with the instructions in this User Guide.

The equipment has not been subject to misuse either intended or accidental, neglect, or alteration other than as described in the User Guide or Service Manual, or approved by ALLEN & HEATH.

Any necessary adjustment, alteration or repair has been carried out by an authorised ALLEN & HEATH distributor or agent.

This warranty does not cover fader wear and tear.

The defective unit is to be returned carriage prepaid to the place of purchase, an authorised ALLEN & HEATH distributor or agent with proof of purchase. Please discuss this with the distributor or the agent before shipping.

If the unit is to be repaired in a different country to that of its purchase the repair may take longer than normal, whilst the warranty is confirmed and parts are sourced.

Units returned should be packed to avoid transit damage.

In certain territories the terms may vary. Check with your ALLEN & HEATH distributor or agent for any additional warranty which may apply.

If further assistance is required please contact Allen & Heath Ltd.



The GLD range of products complies with the European Electromagnetic Compatibility directives 89/336/EEC & 92/31/EEC and the European Low Voltage Directives 73/23/EEC & 93/68/EEC.

Any changes or modifications to the equipment not approved by Allen & Heath could void the compliance of the product and therefore the users authority to operate it.

GLD User Guide AP8561 Issue B

Copyright © 2012 Allen & Heath. All rights reserved

ALLEN & HEATH

Allen & Heath Limited, Kernick Industrial Estate, Penryn, Cornwall, TR10 9LU, UK

<http://www.allen-heath.com>

IMPORTANT - Read these instructions before starting:

Safety instructions

Before starting, read the [Important Safety Instructions](#) printed on the sheets supplied with the equipment. For your own safety and that of the operator, technical crew and performers, follow all instructions and heed all warnings printed on the sheet and on the equipment panels.

System operating firmware

The function of the GLD is determined by the firmware (operating software) that runs it. Firmware is updated regularly as new features are added and improvements made. The latest firmware and update instructions are available from the Allen & Heath web site.

Firmware can be downloaded from the Allen & Heath web site, transferred to USB key and then loaded into the GLD mixer using the Firmware Update utility. If the AudioRack firmware is different to that running on the mixer it is automatically updated by the GLD mixer when the mixer powers up.

- Check the Allen & Heath web site for the latest version of GLD firmware.

Software licence agreement

By using this Allen & Heath product and the software within it you agree to be bound by the terms of the relevant [End User Licence Agreement](#) (EULA), a copy of which can be found on the Allen & Heath website in the product's pages and in the About section of the GLD built-in Help Manual. You agree to be bound by the terms of the EULA by installing, copying, or using the software.

Further information



For further information about the GLD refer to the user guides associated with each system component. Also use the on-screen [Help Manual](#) available on the GLD-80 surface. For additional downloads, resources, knowledgebase and technical support refer to the [Allen & Heath web site](#).

General precautions


- To prevent damage to the controls and cosmetics, avoid placing heavy objects on the control surface, obstructing movement of the motorised faders, scratching the surface or touch screen with sharp objects, or rough handling and vibration.
- Protect the equipment from damage through liquid or dust contamination. Avoid dust or small objects getting into the fader slots. Cover the mixer when it is not being used for a long period.
- Computer and touch screen technology can be affected by extreme cold. If the equipment has been stored in sub-zero temperatures allow time for it to reach normal operating temperature before use at the venue. Recommended operating temperature for iLive is 5 to 35 degrees Celsius.
- Avoid using the equipment in extreme heat and direct sunlight. Make sure the mixer and rack ventilation slots are not obstructed and that there is adequate air movement around the equipment.
- Transport the GLD-80 using a touring grade, purpose designed flightcase with adequate foam lining and internal support for protection.
- Avoid the use of chemicals, abrasives or solvents. Clean the control surface with a soft brush and dry lint-free cloth.
- It is recommended that servicing is carried out only by an authorised Allen & Heath agent. Contact details for your local distributor can be found on the Allen & Heath web site. Allen & Heath do not accept liability for damage caused by maintenance, repair or modification by unauthorised personnel.

Packed contents, registration and accessories

GLD-80 Mixer





User Guide
AP8561




Safety Sheets
AP3345 – English
AP7287 – French
AP8513 – Chinese

- Read this before starting





Registration Card AP3594

- Return the card or register online at www.allen-heath.com




Mains lead • Check this is correct for your territory

GLD-AR2412 AudioRack





Information
AP8596




Safety Sheets
AP3345 – English
AP7287 – French
AP8513 – Chinese

- Read this before starting




Registration Card AP3594

- Return the card or register online at www.allen-heath.com





CAT5 cable
2m (6.6')
AH8822




Mains lead • Check this is correct for your territory

GLD-AR84 AudioRack





Information
AP8720




Safety Sheets
AP3345 – English
AP7287 – French
AP8513 – Chinese

- Read this before starting




Registration Card AP3594

- Return the card or register online at www.allen-heath.com



CAT5 cable
2m (6.6')
AH8822



Mains lead • Check this is correct for your territory

Accessories available

The 2m CAT5 cable shipped with the GLD AudioRack is to get you started or for local connection. For longer distances refer to the Allen & Heath web site for information on recommended cable types. The following are available from Allen & Heath:



120m (396') CAT5 drum
AH8721 • For use with dSNAKE and ACE™ connection only



80m (264') CAT5 drum
AH7000 • For use with all GLD CAT5 connections

LEDlamp

Part LEDlampX

Right angled 4-pin XLR with built-in dimmer



Soft cover for GLD-80
AP8806

Black, water repellent polyester

Table of Contents

Read before starting	3
Packed contents, registration and accessories	4
GLD systems	6
Introduction	7
System block diagram	8
Input and output sockets	9
GLD-80 Mixer controls	10
GLD-80 Mixer rear connectors	11
GLD-AR2412 main AudioRack	12
GLD-AR84 expander AudioRack	13
Connect and power up	14
Recall a Template Show as a starting point	15
A few things to know before starting	17
Specification	22
Dimensions and weights	23
Quick start sheet	24

Important note about this guide

This is a provisional release of the GLD User Guide. It relates to **Version 1.0** pre-release firmware. Some details shown in this guide may differ from those in the current release of firmware. For more information on these and functions not described in this release of the guide please refer to the Help Manual built into the GLD mixer and to the GLD pages on the Allen & Heath web site.

- Check the Allen & Heath web site for the latest version of this guide.
- Check the Allen & Heath web site for the latest version of GLD firmware.
- Refer to the GLD mixer built-in **Help Manual** for more information.
- A single sheet **Quick Start Mixing Guide** is provided at the rear of this user guide.




Systems

GLD-80 only 8 in (4 mics), 10 out
4 mics at mixer
Can use I/O module option for networked audio



Standard system 32 in (28 mics), 22 out
24 mics at rack, 4 mics at mixer

GLD-80 x1
GLD-AR2412 x1
Connect to dSNAKE



Compact system 16 in (12 mics), 14 out
8 mics at rack, 4 mics at mixer

GLD-80 x1
GLD-AR84 x1
Connect to EXPANDER




Expanded system 40 in (36 mics), 26 out
32 mics at racks, 4 mics at mixer

GLD-80 x1
GLD-AR2412 x1
GLD-AR84 x1
Connect to dSNAKE



Fully expanded system 48 in (44 mics), 30 out
40 mics at racks, 4 mics at mixer

GLD-80 x1
GLD-AR2412 x1
GLD-AR84 x2
Connect to dSNAKE and EXPANDER



Introduction

GLD is an affordable live sound digital audio mixing system from Allen & Heath. At its low price point and with its intuitive user interface and 'plug n play' connection it provides the perfect upgrade for users of analogue mixers such as the Allen & Heath GL Series, and for small to mid-sized venues, tours and rental companies looking for an affordable yet fully featured and configurable professional digital solution that is easy to learn, operate and maintain.

GLD components

The heart of the system is the **GLD-80 Mixer**. The DSP is located in the mixer and can process 48 channels x 30 buses x 20 mix outputs plus 8 'RackFX' internal effects devices with dedicated return channels bringing the total number of sources able to feed the mix to 56. The rear panel provides connections for 8 inputs and 10 outputs plus an option slot to fit one of several audio networking cards available from Allen & Heath.

Adding one or more of the available AudioRacks lets you configure systems with up to 40 remote mic inputs in addition to the mixer rear connections. This gives you a distributed audio system with convenient CAT5 digital snake based on the proprietary Allen & Heath dSNAKE protocol. The main I/O (Input/Output) rack is the **GLD-AR2412 AudioRack** providing 24 mic/line inputs and 12 line outputs. It also features a MONITOR port compatible with the Aviom™ personal monitor system. The **GLD-AR84 AudioRack** is an expander I/O remote rack adding an extra 8 mic/line inputs and 4 line outputs. You can add up to two GLD-AR84 racks, one at the GLD-AR2412, the other at the GLD-80 mixer.

Compatibility with iLive

GLD is not compatible with iLive components, firmware, Libraries or Show files. However, it is compatible with the range of iLive Port B option cards letting you interface easily between GLD and iLive or other systems using a digital snake such as ACE, MAD1, EtherSound or Dante.

Key features


- Plug n play components for systems from 4 to 44 mics
- Easy to use, quick access, analogue style interface
- Remote I/O using dSNAKE CAT5 digital snake - up to 120m (400') length
- High grade 1dB/step recallable mic/line preamps
- 48 channels into 30 buses into 20 outputs – assignable mono/stereo Group, Aux, FX, Main, Matrix
- 8 stereo RackFX engines with dedicated return channels – total 56 sources to the mix
- Full processing on all inputs – Preamp, trim, polarity, HPF, insert, Gate, PEQ, Compressor, Delay
- Full processing on all outputs – Ext input, Insert, PEQ, GEQ, Compressor, Delay
- Input, insert and output soft patchbays
- 20 faders, 2 Banks of 4 Layers each – 80 freely assignable strips for custom layout
- 8.4" colour touch screen
- Virtual write-on strip – 8 colour backlight LCD strip display for naming and colour coding
- 10 user assignable SoftKeys
- Dedicated keys for quick Copy/Paste/Reset of mixes and processing parameters
- 16 DCA / Mute groups
- I/O network card option for FOH/Monitor split, recording, link to iLive and more
- MONITOR port for personal monitor systems – Aviom™ compatible
- Built-in Talkback, RTA display, Signal Generator
- Monitor mode features – Input override output PAFL, engineer's Wedge and IEM strips
- MIDI In/Out and Network ports
- Libraries, Scenes and Show memories
- Get started quickly with Template Shows for classic FOH or Monitor configuration

System block diagram

The block diagram here shows the audio signal flow and processing through the GLD-80.

The GLD-AR2412 and GLD-AR84 AudioRacks provide inputs as shown in the 'Remote Inputs' box, and outputs as shown in the 'Remote Outputs' box. These signals connect to the GLD-80 via the dSNAKE or EXPANDER ports.

Note the options available for AUX sends, FX sends and global Direct Out. Configuration possibilities are shown for the MIX masters.




Input and output sockets

The diagram here shows the interconnection and socket numbering of the fully expanded system.

Each socket has a unique number. The physical socket numbers are shown below. Any input socket or source can be patched to any of the 48 channels. Any mix or other GLD signal can be patched to any of the output sockets.

The default is one-to-one mapping, ie. Socket 1>CH1, Socket 2>CH2 and so on.



GLD-80 Mixer controls

Channel Processing Strip Analogue style processing control section presenting the main controls for the Preamp, HPF, Gate, PEQ and Compressor. Press the strip **Sel** key to access the processing for the input or master assigned to it. Further parameter control is available using the touch screen **Processing** screen.

Touch Screen For status display, system setup and memory management. To see details and a graphical view of the processing for the channel or master currently selected make sure it is in **Processing** mode. The keys select the screen mode. Use the rotary control to adjust the value of a highlighted parameter.

Routing select key to display the assignments and sends for the **Selected** strip in the touch screen while in **Processing** mode.

Main / PAFL meters

USB ports For transferring Show files, Libraries and event logs, stereo playback and recording to USB, and for updating system firmware.

Strip LCD display to show channel status information and user defined Name and Colour.

Strip rotary controls
Their function is selected using these keys – Gain, Pan, Custom 1 and 2 (assignable using the **Setup / Control** screen).

Headphones Level control and 1/4" and 3.5mm sockets.

Strip meters The top red indicator lights when a peak is detected at any point in the channel signal path. These meters also display RTA activity while in GEQ on Faders mode.

Press to Talk
Talkback source and destination is assigned using the **Setup / Audio** screen.

Help Touch the **?** button to open the built-in **Help Manual**

SoftKeys 10 keys with function assigned using the **Setup / Control** screen.



Fader Banks 2 groups of motorised faders with 4 layers each (80 control strips). Provides control of the Input channel, FX return, Mix master, DCA or engineer's Wedge or IEM monitor assigned to it using the **Setup / Control** screen.

Copy/Paste/Reset Hold Copy down and press any **Sel** or **Mix** key to put its related mix or processing parameters on to the clipboard. Then hold down Paste and press a strip **Sel** or **Mix** key to paste its contents to that channel. Hold Reset and press a key to reset the related parameters to factory default.

Mute mutes the channel assigned to the strip. It affects pre and post-fade sends. The DCA indicator lights when the channel is muted by a DCA master assigned to it.

Assign and Pre/Post access keys for the selected mix.

While a Mix is active:

Hold down **Assign** and press strip **Mix** keys to toggle the assignments on or off.

Hold down **Pre/Post** and press strip **Sel** keys to toggle sends pre or post fade.

Toggle all on/off or pre/post while a master is selected by pressing the master strip **Mix** or **Sel** key instead of the channel keys.

The touch screen lower toolbar displays the currently selected mix. You can return to the Main mix by turning the selected **Mix** off, or by turning on then off any other **Mix** key.

Alt View Hold down to view the channel or socket numbers in place of the name in the LCD displays. Set this preference in the **Setup / Control** screen.

Safes Make one or more channels safe from Scene recall by holding down the Safes key and then pressing channel **Mix** keys. A **Safes Map** is also available to make selected parameters safe.

Freeze in Layers Hold down then press strip **Mix** keys to temporarily keep a channel visible across all layers. To assign channels to strips use the **Setup / Control** screen.

GEQ on Faders Presents the GEQ for a **Selected** mix on the faders. Press to toggle between high and low frequencies. Frequency values are shown on the strip LCD displays. The mix master fader is presented on the right hand strip while in this mode.

GLD-80 Mixer rear connectors

GLD sockets can be patched using the **I/O** screen.

Surface audio inputs 8 analogue inputs:

4 mic/line XLR (skt 41-44)

2 stereo RCA pairs (skt 45-48)


Any socket can be patched to any channel. The default is one-to-one mapping of sockets to channels.

Power On indicator
Ready indicator – Lights yellow when the output sockets are ready to pass audio after power up.

4-pin XLR **Lamp** socket. We recommend the use of the Allen & Heath LEDlamp with built-in dimmer.

Cooling fan. Do not block this opening.

The **LOCK** indicator lights when the audio is sync locked



Mains power IEC input socket and On/Off switch.



Network
Ethernet port for future use.

I/O Port See below

MIDI in and out

dSNAKE link
This is the GLD-80 to **AR2412** AudioRack link. It carries audio inputs from **skt 1-32** and outputs to **skt 1-16**. It also carries the audio sends to the AudioRack MONITOR port.

Connect using a CAT5 cable up to 120m (396') long.

The **Lnk/Err** indicator flashes at a steady rate when the link is established.

EXPANDER link
You can plug an **AR84** expander in here. This carries audio inputs from **skt 33-40** and outputs to **skt 17-20**.

The AR84 can be located near the GLD-80 to provide more I/O at the mixer, or up to 120m away to provide more I/O on stage or at a remote location.

Connect to using a CAT5 cable up to 120m (396') long.

The **Lnk/Err** indicator flashes at a steady rate when the link is established.



Surface audio outputs 6 analogue and 4 digital outputs

4 XLR line out (skt 21-24)

1 stereo RCA pair (skt 25/26)

1 SPDIF 2 channel digital out (skt 27/28)

1 AES 2 channel digital out (skt 29/30)

Any GLD signal can be patched to any socket.

I/O Port options for system linking, expansion, recording and audio networking using one of the option cards available from Allen & Heath. 64 channel bi-directional 48kHz audio.



ADAT
iDR out
Aviom™
Hearback

GLD-AR2412 Main AudioRack



① **Input sockets** 24 balanced XLR inputs for microphone and line level sources. The preamps are built into the AR2412 rack and their Gain, Pad and 48V phantom power is remote controlled from the GLD console via the dSNAKE link. The output of the analogue preamps are converted to digital format and transported via dSNAKE to be processed and mixed at the GLD-80 mixer.

The sockets are numbered 1-24. Any input can be patched to any channel using the **I/O** or **Preamplifier** screens. The default is one-to-one mapping of the input sockets 1-24 to channels 1-24.

② **Output sockets** 12 balanced XLR outputs operating at nominal +4dBu line level. Any GLD signal can be patched to any socket using the console **I/O** screen. The default Template Shows provide a logical mapping of these sockets to get you started.

③ **EXPANDER port** CAT5 cable link to connect a GLD-AR84 expander rack to add a further 8 mic/line inputs and 4 XLR line outputs. The GLD system numbers these sockets as Inputs 25-32 and Outputs 13-16.

④ **MONITOR port** CAT5 cable link to connect to a personal monitor system. The port is compatible with the Aviom™ A-16 system.

⑤ **dSNAKE port** CAT5 cable link to connect the AR2412 rack to the GLD-80 mixer. This carries the 32 inputs, 16 outputs and the monitor port sends audio to and from the rack as well as control for the preamps and system status.

Maximum CAT5 cable length is 120m (396') depending on cable type.

- Note that dSNAKE is not compatible with the iLive ACE connection.




⑥ **Fan** A low noise fan ensures air movement through the rack to keep the circuits within operating temperature range.

- Ensure good ventilation at the back of the rack. Read the safety instructions printed on the panel and the Safety Sheet packed with the unit.

⑦ **Mains power input** IEC connector, fuse and power ON/OFF push switch for the built-in universal voltage power supply unit. This accepts worldwide voltages from 100 to 240V AC 50/60Hz. Check that you have received the correct mains lead for your territory.

Secure the cable in place using the plastic P-clip. Use a T20 Torx screwdriver to refit the screw.

GLD-AR84 Expander AudioRack



① **Input sockets** 8 balanced XLR inputs for microphone and line level sources. The preamps are built into the AR84 rack and their Gain, Pad and 48V phantom power is remote controlled from the GLD console via the EXPANDER link. The output of the analogue preamps are converted to digital format and transported via a Cat5 cable to be processed and mixed at the GLD-80 mixer.

Any input can be patched to any channel using the **I/O** or **Preamp** screens.

The sockets are not numbered. This is because the number depends on where the AR84 is plugged into the GLD system. Write-on blocks are provided for you to label the sockets.

② **Output sockets** 4 balanced XLR outputs operating at nominal +4dBu line level. Any GLD signal can be patched to any socket using the console **I/O** screen. The default Template Shows provide a logical mapping of these sockets to get you started.

The sockets are not numbered. This is because the number depends on where the AR84 is plugged into the GLD system. Write-on blocks are provided for you to label the sockets.

The socket identification is shown in the diagram below:

③ **EXPANDER port** CAT5 cable link to connect the AR84 expander to the EXPANDER port on the AR2412 AudioRack or GLD-80 Mixer.

- Note that the EXPANDER link is not compatible with the iLive ACE connection.

④ **Kensington security slot** To attach a 'Kensington lock' standard anti-theft cable and lock if required.

⑤ **Fan** A low noise fan inside the rack ensures air movement to keep the circuits and internal components within operating temperature range.

- Ensure good ventilation at the back of the rack. Read the safety instructions printed on the panel and the Safety Sheet packed with the unit.

⑥ **Mains cable clip** You can secure the cable in place using the plastic P-clip. Use a T20 Torx screwdriver to refit the screw.

⑦ **Mains power input** IEC connector, fuse and power ON/OFF push switch for the built-in universal voltage power supply unit. This accepts worldwide voltages from 100 to 240V AC 50/60Hz. Check that you have received the correct mains lead for your territory.

Socket numbering

AR84 plugged into the AR2412 main AudioRack:

Inputs 25-32 Outputs 13-16




AR84 plugged into the GLD-80 Mixer:

Inputs 33-40 Outputs 17-20



Connect and power up



Connect the AR2412 AudioRack Plug a CAT5 cable into the dSNAKE port at the rack and mixer. This is the main system link.

Connect the AR84 AudioRacks Plug a CAT5 cable into the EXPANDER port of the AR84 and the EXPANDER port of the AR2412 or GLD-80 mixer.


- Always plug the AR84 into an EXPANDER port. Do not plug it into the dSNAKE port even if you are not using an AR2412 main rack.

Plug in the mains power leads supplied with the mixer and racks. Secure the leads by hooking them into the plastic clips. If required the leads can be locked into these clips. Use a T20 Torx (starhead) screwdriver to remove the fixing screw.

To turn on the system Turn on power using the rear panel On/Off switches.

The GLD-80 takes around 30 seconds to boot up. Its screen lights white for a few seconds, then turns black displaying its boot sequence. A while later the **Home** screen is displayed. At this point the yellow **Lnk/Err** indicators of connected dSNAKE and EXPANDER ports start to flash steadily showing that the link between the mixer and racks is established. The mixer Audio Sync **LOCK** indicator lights. Finally, the AudioRack **Ready** indicators light and you will hear a click as the output socket protection relays switch over.

- If the **firmware** in a connected AudioRack is not the same version as that in the GLD-80 then the mixer will automatically update the rack firmware during power up. This takes a few seconds. During this time the **Lnk/Err** indicators on the AudioRack flash at a fast rate. Once updated normal flash rate is restored.



To turn off the system The system must be powered down correctly. Return to the **Home** screen. To do this turn off any active **Sel** key whilst in the **Processing** view.

Touch the **Power Down** button. A popup appears. Confirm the action then turn the mixer and racks off using their power switches.

- If the system is not powered down correctly there is a possibility recent changes may be lost.
- If the system was not powered down as described above then a **'Not shut down correctly'** screen appears the next time the system is turned on.



Recall a 'Template Show' as a starting point

The GLD has a fully configurable audio architecture, control layout and socket patching letting you customise the way you work. It would be a daunting task for the new user if we gave them a 'blank canvas' to start from scratch. Instead we have provided a set of 'Template' Show memories which give you a choice of classic console format to load in as a quick starting point. These present the familiar architecture and logical layout of well equipped analogue consoles. Once you are comfortable working with GLD you can make changes to your set up and save these as your own 'User' Shows.

A default show is already loaded when the iLive is shipped from the factory. This is [FOH_Config1_LR](#).




To load a Template Show Go to the **Setup / Memory / Show Manager** screen. Available Shows are listed. These include Template and User Shows.

Touch the **Template Show** you want to load. Touch **Recall**. A popup appears for you to confirm the action.

- Recalling a Show overwrites all the system settings including the DSP mix architecture, Surface configuration, current parameters, all the Scene and Library memories. If you want to keep the current settings to be used again in the future then first **Store** them as a **User Show**.



There are 4 Template Shows available:



FOH_Config1_LR

This Template configures a traditional architecture and layout with stereo LR main mix for mixing FOH and Monitors from FOH:


- LR stereo main mix
- 4 Groups (2 stereo)
- 8 Auxes (6 mono, 1 stereo)
- 8 FX (4 assigned to strips)
- 6 Matrix (2 mono, 2 stereo)
- 16 DCA / Mute groups
- Talkback using mic socket 44



FOH_Config2_LRM

This Template configures stereo LR plus Mono bus for mixing 3 speaker FOH and Monitors from FOH:

- LR + Mono (switched bus) main mix
- 2 Groups (1 stereo)
- 8 Auxes (6 mono, 1 stereo)
- 8 FX (4 assigned to strips)
- 6 Matrix (2 mono, 2 stereo)
- 16 DCA / Mute groups
- Talkback using mic socket 44



FOH_Config3_LCR

This Template configures LCR for mixing 3 speaker FOH and Monitors from FOH:

LCR pan main mix

2 Groups (1 stereo)



8 Auxes (6 mono, 1 stereo)

8 FX (4 assigned to strips)

6 Matrix (2 mono, 2 stereo)

16 DCA / Mute groups

Talkback using mic socket 44



Monitor_6m6st

This Template configures the GLD as a dedicated monitor console with 18 mixes:


6 mono mixes (wedges, fills)

6 stereo mixes (IEM)

Auto switching engineer's Wedge/IEM

8 FX (2 assigned to strips)

Talkback using mic socket 44



A few things to know before starting

Before working with the GLD familiarise yourself with its control layout and operating principles.

The Touch Screen


Screen **graph view** for PEQ and dynamics:

Touch a pick-up box and drag the curve. Values are displayed in the parameter buttons.

You can adjust parameters using the graph, touch buttons or processing section rotary controls to the left of the screen.

Name and Colour button

Tabs to select the pages available for the current screen



Screen select keys:

Press a key to select that view. Press the key again to return to **Processing** view.

Screen rotary control:

Touch a parameter on the screen to highlight it, then turn the rotary to adjust its value.

- Processing
- Meters
- FX
- I/O
- Scenes
- Ganging
- Setup

Pullup tab opens additional controls and options for the current screen

The Home Screen

This screen displays after power up. You can return here by turning off any active strip **Sel** key while in the screen **Processing** view. You can also do this by turning on, then off any strip **Sel** key.

Returns to this screen

Access the User login screen

Opens the Quick Start Mixing Guide

To safely shut down the GLD computer before turning the system off.

● Always shut down using this button.

Displays system connection status

Displays system information



Real time **clock**. Set the date and time using the **Setup / Utility / Date/Time** screen.

To **lock** the surface controls. Can be password protected.

Tabs to open one of the 4 custom meter pages or the RTA (real time analyser) display. The RTA follows the PAFL signal. Custom meters are assigned using the **Meters** screen.


Touch **?** to open the Help page for the current screen. You can also access the main Help menu from here.

Shows which **Mix** is currently selected.

● Look here to check that you are on the correct mix. For example, remember to turn off an Aux **Mix** key to return to the **Main** (LR) mix after adjusting a monitor level.


The strip LCD display

The LCD strip above the faders displays information about the channels assigned to the faders. Channels can each be named and have one of 8 backlight colours applied. You can edit these names and colours to easily identify different channel and mix types, or highlight certain instruments and sources.



Select the function of the strip Rotary controls using these keys. The Custom keys are assigned using the **Setup / Control / Surface Prefs** screen.

- Check that you have selected the correct function when working with the rotary controls.



Press and hold the **Alt View** key to see the Channel Number, Socket Number or fader dB value in place of the Name in the LCD display.

Choose the Alt View function using the **Setup / Control / Surface Prefs** screen.

The Fader Banks

There are 2 independent Fader Banks, one with 12 fader strips, the other with 8 fader strips. Each Bank has 4 Layers. This means that the GLD-80 can work with up to 80 fader control strips.

Any strip can be assigned as an Input channel, Mix master, FX send master, FX Return, engineer's Wedge or IEM master, or DCA master in any combination. Strips can be left blank (unassigned). The Template Shows provide a logical assignment of the fader strips to give you a familiar starting point.

To change the fader strip assignment use the **Setup / Control / Strip Assignment** screen. You can drag-and-drop to quickly reassign the strips.



The Fader Strip keys

4 keys per strip provide quick access to important live mixing functions:

Lights when the channel is muted by a DCA

Mute Turns off the channel signal. Affects the main mix and pre-fade and post-fade sends. This is important in live mixing, for example to mute an acoustic guitar in both the FOH mix and monitors when the musician unplugs it.

Sel Instantly selects the processing for the channel. The rotary control section to the left of the touch screen becomes active to control the Preamp, HPF, PEQ, Gate and Compressor for that channel.

- To see and adjust the processing using the touch screen make sure the screen **Processing** key is selected.

Mix Puts the send levels and assignments of the associated channel or master onto the fader strips. For example you can work with all the sends to one Aux shown on the input faders by selecting its master strip **Mix** key. Or work with the sends from one channel to all the Auxes shown on the master faders by selecting the channel **Mix** key.


- Be aware of which Mix is currently selected. For example, when you have finished adjusting an Aux send, press its **Mix** key again to turn it off and return to the main mix. The currently selected mix is displayed in the lower left screen toolbar.

PAFL Sends the channel PFL (pre-fade listen) or AFL (after-fade listen) signal to the GLD headphones and monitoring system. Preferences for the PAFL system are set using the **Setup / Audio / PAFL** screen.

Input PAFL overrides mix master PAFL.

Working with the Mix on the fader strips

Normal mix mode (FOH)




Press a Main Mix master strip **Mix** key.

This is the normal mixing mode. The Input strips present the channel faders. The Master strips present the master mix faders.

Hold down the **Assign** key and press channel **Mix** keys to assign or de-assign them from the main mix. Current ON status is displayed on the lower part of the strip LCDs.

Master Mix view



Press a Mix master strip **Mix** key.


Use this to work with Aux and FX sends. The Input strips change to present all the send levels to the selected mix. The Master strips present the master mix faders.

Hold down the **Assign** key and press channel **Mix** keys to assign or de-assign them from the selected mix.

Hold down the **Pre/Post** key and press channel **Sel** keys to toggle each source pre or post fader. Current PRE status is displayed on the lower part of the channel strip LCDs.

You can quickly set **all** assignments on or off, or all sources pre or post fader by pressing the Master strip **Mix** or **Sel** key instead of a channel key as described above.

Channel Mix view




Press an Input Channel strip **Mix** key.

Use this to work with Aux and FX sends. The Input strips remain as Channel Faders. The Master strips change to present all sends from the selected channel.

Hold down the **Assign** key and press master **Mix** keys to assign or de-assign the channel from each mix.

Hold down the **Pre/Post** key and press master **Sel** keys to toggle the channel pre or post fader to each mix. Current status is displayed on the master strip LCDs.

DCA and Audio Group assign



Press a Group Master strip **Mix** key.

Use this to assign channels to the Audio and DCA groups. The Input and Master faders are not affected.

Hold down the **Assign** key and press channel **Mix** keys to assign or de-assign the channels from the group.


Specification

Inputs	
XLR Mic/Line Inputs	Balanced, (All XLR on GLD-80 and AudioRacks)
Mic/Line Preamp	Fully recallable
Input Sensitivity	-60 to +15dBu
Analogue Gain	+5 to +60dB, 1dB steps
Pad	-20dB
Maximum Input Level	+32dBu
Input Impedance	>4kΩ (Pad out), >10kΩ (Pad in)
Mic/Line Channel noise	20-20kHz, Direct Out @ unbalanced out
Mic EIN	-127dB with 150Ω source
Unity gain (Pad in)	-90dBu
Low gain (5dB, Pad out)	-93dBu
Mid gain (30dB, Pad out)	-89dBu
Mic/Line Channel THD+N	20-20kHz, Direct Out @ unbalanced out
Unity gain (Pad in)	0.005% -86dBu @ 1kHz, 0dBu output
Low gain (5dB, Pad out)	0.003% -89dBu @ 1kHz, 0dBu output
Mid gain (30dB, Pad out)	0.004% -88dBu @ 1kHz, 0dBu output
RCA Line Inputs	Unbalanced (GLD-80)
Input Sensitivity	-24 to +24dBu, nominal 0dBu
Trim	+/-24dB, recallable
Maximum Input Level	+18dBu
Input Impedance	>10kΩ
RCA channel Noise	-92dBu 20-20kHz
RCA channel THD+N	0.0035% -90dBu @ 1kHz, 0dBu output
Outputs	
XLR Outputs	Balanced, Relay protected
Output Impedance	<75Ω
Nominal Output	+4dBu = 0dB meter reading
Maximum Output Level	+22dBu
Residual Output Noise	-91dBu (muted, 20-20kHz)
RCA Line Outputs	Balanced, Relay protected
Output Impedance	<75Ω
Nominal Output	0dBu = 0dB meter reading
Maximum Output Level	+18dBu
Residual Output Noise	-94dBu (muted, 20-20kHz)
Digital Outputs	48kHz sampling rate
SPDIF	RCA, 600mV, coax terminated input 75Ω
AES3 2 ch XLR output	XLR, 2.5Vpp balanced terminated 110 Ω
System	
Measured balanced XLR in to XLR out, 20-20kHz, minimum Gain, Pad out	
Dynamic Range	112dB
System Signal to Noise	-90dB
Frequency Response	0/-0.25dB @ 20Hz, 0/-0.5dB @ 20kHz
System peak level THD+N	0.0055% -68dBu @ +17dBu output, 1kHz
System Line level THD+ N	0.0022%, -84dBu @ +9dBu output, 1kHz
Headroom	+18dB
Internal operating Level	0dBu
dBFS Alignment	+18dBu = 0dBFS (+22dBu at XLR output)
Meter Calibration	0dB meter = -18dBFS (+4dBu at XLR out)
Meter Peak indication	-3dBFS (+19dBu at XLR out)
Meter Type	Fast (peak) response
Sampling Rate	48kHz +/-100PPM
ADC	24-bit Delta-Sigma
DAC	24-bit Delta-Sigma
Latency	1.49ms (GLD-80 local XLR in to XLR out) 0.68ms (GLD-80 local XLR in to digital out)
USB Playback	2 channel, WAV, MP3, M4A, FLAC
USB Record	2 channel, 44.1kHz / 16bit - WAV
I/O Port	64 channel bi-directional
Card Options	A&H ACE, MADI, Dante, ES, Waves, MMO
Operating Temperature Range	0 deg C to 35 deg C (32 deg F to 95 deg F)
Mains Power	
GLD-80	100-240V AC, 50/60Hz, 95W max
GLD-AR2412	100-240V AC, 50/60Hz, 70W max
GLD-AR84	100-240V AC, 50/60Hz, 20W max

Control	
Faders	100mm motorised
Fader Banks	2 Independent banks - 12, 8 faders
Touch Screen	8.4" TFT, 800x600 resolution
Control Strips	4 Layers per Bank = 80x strips
Strip Display	LCD per strip, assignable backlight colours
SoftKeys	10 assignable
MIDI	MIDI In and Out
Network	TCP/IP Ethernet (for future application)
Input Processing	
48 Input Processing Channels	Mono = 1-44, Stereo = 45/46, 47/48
Trim	+/-24dB digital trim
Polarity	Normal/Reverse
High Pass Filter	12dB/octave 20Hz – 2kHz
Insert	Assign to any sockets, In/Out, +4dBu/-10dBV level
Delay	Up to 85ms Input global setting - ms, feet, meters, samples
Gate	
Sidechain	Self key, In/Out, Sel 'listen'
Sidechain Lo-Cut Filter	12dB/octave, Freq 20Hz – 5kHz
Sidechain Hi-Cut Filter	12dB/octave, Freq 120Hz – 20kHz
Threshold	-72dBu to +12dBu
Depth	0 to 60 dB
Attack	50us to 300ms
Hold	10ms to 5s
Release	10ms to 1s
PEQ	
Type	4-Band fully parametric, +/-15dB
Frequency Range	Global setting for Inputs = 20-20kHz or 'Analogue'
Analogue Ranges	20-200Hz, 35-1kHz, 500-15kHz, 2k-20kHz
Band 1	Selectable LF Shelving, Bell, Hi-Pass
Band 2	Bell
Band 3	Bell
Band 4	Selectable HF Shelving, Bell, Lo-Pass
Bell Width	Non-constant Q, variable, 1.4 to 1/9th octave
Shelving Type	Classic Baxandall
Hi-Pass, Lo-Pass Filter	12dB/octave
Compressor	
Sidechain	Self key, In/Out, Sel 'listen'
Sidechain Lo-Cut Filter	12dB/octave, Freq 20Hz – 5kHz
Sidechain Hi-Cut Filter	12dB/octave, Freq 120Hz – 20kHz
Threshold	-46dBu to 18dBu
Ratio	1:1 to infinity
Attack	300us – 300ms
Release	100ms – 2s
Knee	Soft/Hard
Manual Types	Peak Manual, RMS Manual
Auto Types	VocalAuto, OptoAuto, PunchBag
Channel Direct Out	Individual Trim (per channel)
Options	Source, follow Fader, follow Mute (global for all)
Mix Processing	
20 Mix Processing Channels	Configure as mono/stereo Groups, Aux, Main, Matrix Mains = None, LR, LCR, LR+M(bus), LR+M(sum)
External Input	Assignable source
Trim	+/-24dB digital trim
Polarity	Normal/Reverse
Insert	Assign to any sockets, In/Out, +4dBu/-10dBV level
Delay	Up to 170ms Mix global setting - ms, feet, meters, samples
GEQ	
Type	Constant 1/3 octave, 28 bands 31Hz -16kHz
Gain	+/-12dB
GEQ Fader Flip Mode	2 overlapping frequency banks on strip faders layer 1 - 31-1kHz + Mix master fader layer 2 - 500-16kHz + Mix master fader SEL key resets frequency band to 0dB RTA following PAFL is displayed on strip meters

FX Processing	
Internal FX	8x RackFX engine
Types	Reverbs, Delays, Modulators, Sub-harmonics
Mode	Send>Return, Inserted, Daisy Chain FX
FX 'Short' Return Channels	
8 Stereo dedicated returns	Adds to inputs for up to 56 sources to the mix
Controls	Fader, Pan, Mute, Routing to Grp, Aux, FX, Main
FX Return PEQ	Same as Input Channel PEQ
Talkback	
High Pass Filter	Assignable source
Routing	12dB/octave, 20Hz-2kHz
	To Groups, Aux, Main, Matrix
Signal Generator	
Sine, Bandpass sweep	Sine, White Noise, Pink Noise, Bandpass Noise
Controls	20-20kHz
Routing	Level, Mute
	To Groups, Aux, Main, Matrix
RTA	
Source	31-Bands 1/3 octave 20-20kHz
Peak Band Indication	Follows selected PAFL source
	Option to display dominant frequency


Dimensions and Weights	
GLD-80 Mixer	
	Width x Depth x Height
Unpacked	730 x 577 x 159mm (28.7" x 22.7" x 6.2")
Packed in shipping box	930 x 730 x 290mm (36.6" x 28.6" x 11.4")
Unpacked weight	16kg (35lbs)
Packed weight	21kg (46lbs)
GLD-AR2412 AudioRack	
	Width x Depth x Height
Unpacked	483 x 220 x 137mm (19" x 8.6" x 5.4") 3U rack
Packed in shipping box	600 x 350 x 250mm (23.6" x 13.7" x 9.8")
Unpacked weight	5kg (11lbs)
Packed weight	6.4kg (14lbs)
GLD-AR2412 AudioRack	
	Width x Depth x Height
Unpacked	483 x 220 x 48mm (19" x 8.6" x 1.9") 1U rack
Packed in shipping box	600 x 330 x 143mm (23.6" x 12.9" x 5.6")
Unpacked weight	3kg (6.6lbs)
Packed weight	4.4kg (9.7lbs)



For the new user or guest engineer to start mixing with GLD. It assumes a mixer already configured for the show. To learn more about configuration, memories and advanced functions read the on-screen Help Manual and User Guide AP8561.

- 1** See where Input and Master **Faders** are by pressing Layer keys A,B,C,D and reading the displays



To change the strip assignments use the **Setup/Control** screen





Press **Alt View** to view channel or socket numbers or fader dB value in place of Name. Set option in **Setup/Control** screen

- 2** See how the **Sockets** are patched using the **I/O** screen.

To change the socket assignments touch and select from drop-down menu



- 3** **Sel** Access the **Channel and Mix processing**




For GEQ on faders press **GEQ Fader Flip** - Master on last fader. RTA on strip meters. RTA follows current selected PAFL


- 4** **Mix** Access the **Sends and Assignments**

Normal mix mode (FOH)

Main **Mix** active




DCA and Audio Group assign




• Press **Mix** again to return to Main mix

Master **Mix** view

Access Aux, FX, Matrix mix on faders



Channel **Mix** view




- 5** Access the **FX**
- > To send to an FX - press FX master **Mix**
 - > To adjust FX parameters - press FX strip **Sel**
 - > To return to the mix use related **FXret** channel

- 6** To **Link parameters** eg, 2 channels for stereo keyboard Use the **Ganging** screen. Choose attributes.
- Ganging does not link the Gains or Trims.

- 7** To **Copy parameters**

> Hold down **Copy** and press the **Sel** or **Mix** key of the parameters to copy:



> Now hold down **Paste** and press the **Sel** or **Mix** key of the **strip** to paste to