


GGO-230L FAQ

How to use the FM Radio?

The Gemini GGO-230L features an FM radio tuner so you can access your favorite local stations. Follow these steps accordingly:

1. Long press POWER button (7) to turn the speaker on.
2. Press MODE button (3) to select FM radio mode.
3. Once in FM mode, long press the PLAY button (6) to automatically scan for available FM radio frequencies.
4. Once stations have been saved, you may Long press the Volume “+” (9) & “-” (1) buttons to skip to previous/next saved station.
5. Short press of Volume “+” (9) & “-” (1) buttons to adjust playback volume.



gemini

