Part Number Guide

Neutrik[®] Part Number Guide

AH1-0-X		
→ Shell:	В	Black shell, gold contacts
	BAG	Black shell, silver contacts
Retention:	w/o	Latch Lock
	-0	Retention Spring
Grounding:	0	Separate ground contact connected to shell, male only
	1	Pin 1 & Panel & Shell connected, no separate ground contact
	2	Separate ground contact connected to shell & panel, separate Pin
	E	Additional ground contacts
	w/o number	No ground / Shell contact (except 4 / 5 pole), female only
Termination:	Н	Horizontal PCB mount
	HL	Laterial left PCB mount
	HR	Laterial right PCB mount
	L	Solder Cups
	V	Verticale PCB mount
	Υ	IDC for wires (no ground)
	M3	Mounting holes with M3 thread
	M25	Mounting holes with M2.5 thread
	-	Not applicable
Series:	A, AA, B, BA, D,	DL, DLX, MPR, P, X, XX
Gender:	F	Female
	М	Male
→ Number of Contac	ts: 3, 4, 5, 6, 7, 8, 1	2
Connector Type:	Α	Adapter
	AC	PowerCon*
	В	BNC
	С	Connector
	E	RJ45
	F	RCA / CINCH
	J (MJ, RJ, SJ)	Jack
	K	Cable Assemblies
	L	Loudspeaker
	М	Modules
	0	Fiber Connector
	P	Plugs
	PP	Patch Panel
	R	Circular Connector
	Т	Transformer